



Operation and Safety Manual

AR14J/AR16J

Mobile Elevating Work Platform

 WARNING
--

Before operation and maintenance, the drivers and service personnel shall always read and thoroughly understand all information in this manual. Failure to do so may result in, fatal accidents or personal injury.

This manual must be kept with this machine at all times.

This page left blank intentionally

Contents

Foreword.....	III
Safety Precautions.....	IV
Chapter 1 Safety.....	1
1.1 Danger.....	3
1.2 No Operation Is Allowed Unless.....	3
1.3 Classification of Hazards.....	3
1.4 Intended Purpose.....	3
1.5 Safety Sign Maintenance.....	3
1.6 Risk of Electric Shock.....	4
1.7 Risk of Tipping.....	4
1.8 Safety in the Work Area.....	4
1.9 Risk of Crushing.....	5
1.10 Risk of Operating on Slopes.....	6
1.11 Risk of Falling.....	6
1.12 Risk of Collision.....	6
1.13 Risk of Component Damage.....	7
1.14 Risk of Explosion and Fire.....	7
1.15 Risk of Machine Damage.....	7
1.16 Risk of Bodily Injury.....	7
1.17 Battery Safety.....	7
1.18 Locked After Each Use.....	8
1.19 Check Tires and Wheels.....	8
Chapter 2 Legend.....	9
Chapter 3 Decals.....	14
Chapter 4 Specification.....	23
Chapter 5 Control Unit.....	43
5.1 Lower Control Box.....	45
5.2 Upper Control Box.....	48
Chapter 6 Pre-Operation Inspection.....	55
6.1 No Operation Is Allowed Unless.....	57
6.2 Basic Principles.....	57
6.3 Pre-Operation Inspection.....	57
Chapter 7 Workplace Inspection.....	59
7.1 No Operation Is Allowed Unless.....	61
7.2 Basic Principles.....	61
7.3 Workplace Inspection.....	61
Chapter 8 Functional Test.....	63
8.1 No Operation Is Allowed Unless.....	66
8.2 Basic Principles.....	66
8.3 Functional Test.....	66

8.4 Tests from the Lower Control Box.....	66
8.5 Tests from the Upper Control Box.....	67
Chapter 9 Operating Instructions.....	70
9.1 No Operation is Allowed Unless.....	72
9.2 Basic Principles.....	72
9.3 Starting the Engine.....	72
9.4 Emergency Stop.....	72
9.5 Auxiliary Power.....	73
9.6 Operation from the Ground Control Station.....	73
9.7 Operation from the Platform Control Station.....	73
9.8 Platform overload.....	75
9.9 Tilt Indicator.....	75
9.10 System Fault.....	75
9.11 Parking and Storage.....	77
9.12 Instructions for skyguard.....	77
9.13 Fall protection.....	77
Chapter 10 Instructions for Transportation and Lifting.....	78
10.1 Compliance.....	80
10.2 Freewheel configuration for trailers.....	80
10.3 Transportation Safety.....	80
10.4 Lifting instructions.....	81

Foreword

Thank you for choosing to use this Mobile Elevating Work Platform from LGMG. The information specified in this manual is intended for the safe and proper operation of this machine for its' intended purpose.

For maximum performance and utilization of this machine, thoroughly read and understand all the information in this manual before starting, operating, or performing maintenance on this machine.

Due to continuous product improvements, LGMG reserves the right to make specification changes without any prior notifications. For any updated information, contact LGMG.

Ensure all preventive maintenance to the machine is performed according to the interval specified in the maintenance schedule.

Keep this manual with this machine for reference at all times. When the ownership of this machine is transferred, this manual shall be transferred with this machine. This manual must be replaced immediately if it is lost, damaged, or becomes illegible.

This manual is copyrighted material. The reproduction or copy of this manual is not allowed without the written approval of LGMG.

The information, technical specifications and drawings in this manual are the latest available when this manual is issued. Due to continuous improvement, LGMG reserves the right to change the technical specifications and machine design without notice. If any specifications and information in the manual are not consistent with your machine, contact the service department of LGMG

WARNING

Only personnel who have been properly trained and qualified to operate or maintain this machine can operate, repair and maintain this machine.

Improper operation, maintenance, and repair are dangerous and can cause personal injury and death.

Before any operation or maintenance, the operator shall thoroughly read this manual. Do not operate, perform any maintenance or make any repairs on this machine before reading and understanding this manual.

The user shall load the platform strictly according to the load rating of the platform. Do not overload the platform or make any modifications to the platform without permission from LGMG.

The operation regulations and preventions in this manual are only applicable for the specified use of this machine.

Safety Precautions

The operator of this machine shall understand and follow the existing safety regulations of state and local governments. If these are unavailable, the safety instructions in this manual shall be followed.

To help prevent accidents, read and understand all warnings and precautions in this manual before operation or performing maintenance.

The safety measures are specified in Chapter 1 Safety.

It is impossible to foresee every possible hazard and the safety instructions in this manual may not cover all safety prevention measures. Always ensure the safety of all personnel and protect the machine against any damage. If unable to confirm the safety of some operations, contact LGMG.

The operation & maintenance prevention measures listed in this manual are only applicable to the specified uses of this machine. LGMG assumes no responsibility if this machine is used beyond the range of this manual. The user and the operator shall be responsible for the safety of such operations.

Do not perform any operation forbidden in this manual in any situation.

The following signal words are applicable for identifying the level of safety information in this manual.

 **Danger:**

An imminent situation, that if not avoided, will result in severe injuries or death. This is also applicable to situations that will cause serious machine damage, if not avoided.

 **Warning:**

A potentially dangerous situation, that if not avoided, may result in severe injuries or death. This is also applicable to situations that may cause serious machine damage, if not avoided.

 **Notice:**

A situation, that if not avoided, may result in minor or intermediate injury. This is also applicable to situations that may cause machine damage or shorten machine service life.

Chapter 1 Safety

1.1 Danger

Failure to follow the instructions and safety rules in this manual may cause death or serious injury.

1.2 No Operation Is Allowed Unless

You have understood and practiced the rules for safe operation of the vehicle in this manual.

- 1) Avoid dangerous situations. Know and understand the safety rules before proceeding with the next step.
- 2) Always perform a pre-operation inspection.
- 3) Always perform a pre-use functional test.
- 4) Check the workplace.
- 5) Use the vehicle only for its intended purpose.
- 6) Read, understand, and follow the manufacturer's instructions and safety rules - safe operation manuals and vehicle labels.
- 7) Read, understand and follow user safety rules and work site regulations.
- 8) Read, understand and follow all applicable government laws and regulations.
- 9) You have received the training on safe operation of the vehicle.

1.3 Classification of Hazards



Classification of hazards

The meanings of symbols, color codes and characters of LGMG's products are as follows:

Security warning symbol: are used for warning of potential personal injuries. Observe all safety instructions below these signs, to avoid situations causing potential personal injury and death.



Red: Signifies dangerous situations. If not avoided, will result in personal death or severe injury.



Orange: Signifies dangerous situations. If not avoided, may result in personal death or severe injury.



Yellow: Signifies dangerous situations. If not avoided, may result in minor or intermediate personal injury.



Blue: Signifies dangerous situations. If not avoided, property loss or damage can occur.

1.4 Intended Purpose

This vehicle is only used to lift operators and their tools and materials to high-altitude workplaces.



It is strictly forbidden to use the machine to carry loads.

1.5 Safety Sign Maintenance

- 1) The operators should always keep in mind their safety when replacing any missing or

damaged safety signs.

- 2) The safety decal should be cleaned with mild soap and water.
- 3) Do not use solvent-based cleaners as they may damage the material of the safety label.

1.6 Risk of Electric Shock

- 1) This machine is not insulated and is not provided with electrical shock protection when it comes into contact with or near electrical wire.



- 2) This machine should be kept an adequate safety distance from power line and electrical equipment according to applicable government laws and regulations and the following table.

Voltage	Required safety distance
0 ~ 300V	No touching
300V ~ 50KV	3.05m
50KV ~ 200KV	4.6m
200KV ~ 350KV	6.10m
350KV ~ 500KV	7.62m
500KV ~ 750KV	10.67m
750KV ~ 1000KV	13.72m

- 3) The effects of strong winds or gusts on the movement of the platform, the swinging and slackening of the wires should be considered.
- 4) If the machine comes into contact with live wires, keep away from the vehicle. No one is allowed to touch or operate the vehicle on the ground or platform before cutting off the power supply.

- 5) Do not operate the machine when there is lightning or storms.
- 6) Do not use the machine as a ground wire when welding.


1.7 Risk of Tipping

The personnel, equipment and materials on the platform may not exceed the maximum load capacity of the platform.

Maximum load	AR14J AR16J
Maximum number of people	2 people
Maximum allowable wind speed	12.5m/s
Maximum platform working load	230kg

1.8 Safety in the Work Area

- 1) The boom can be lifted or extended only when the vehicle is on a solid, flat surface.



- 2) When the platform is lifted, drive speed of AR14J/AR16J may not exceed 0.8km/h.
- 3) The tilt sensor may not be used as a level indicator. The alarm on the turntable will sound only when the vehicle is heavily tilted.
- 4) When the alarm sounds: Do not extend, rotate or lift the boom beyond the horizontal plane. The vehicle should be moved to a solid, flat surface before lifting the platform. If the alarm sounds when lifting the platform, the boom should be telescoped carefully and the platform should be lowered. Do not rotate the boom during lowering. The vehicle should be moved to a solid, flat

surface before lifting the platform.

- 5) For outdoor operation, do not lift the boom when the wind speed may exceed 12.5 m/s. If the wind speed exceeds 12.5 m/s after the boom is lifted, the boom should be lowered and do not continue to operate the vehicle.
- 6) Do not operate the vehicle in strong winds or gusts. Do not increase the surface area of the platform or load. Increasing the area exposed to the wind will reduce the stability of the vehicle.
- 7) Do not operate the vehicle with the upper control box when the platform is caught, jammed, or other nearby objects are blocking its normal movement. If you want to operate the vehicle with the lower control box, you must operate it after all personnel have left the platform.
- 8) In the telescoped state, the vehicle should be operated carefully and slow down when driving on uneven terrain, gravel, unstable or smooth surfaces, near holes or steep slopes.



- 9) When the boom is lifted or extended, the vehicle may not drive on uneven terrain, unstable surfaces, or other dangerous conditions, or near these areas.
- 10) Do not push or pull any object that is outside the platform.
- 11) Do not use the vehicle as a crane.
- 12) Do not place, tie, or hang any loads on any part of the vehicle.



- 13) Do not use the boom to push the vehicle or other object.
- 14) Do not make the boom contact adjacent components.
- 15) The limit button switch may not be changed or disabled.
- 16) The boom or platform may not be tied to adjacent components.
- 17) The load may not be placed outside the perimeter of the platform.
- 18) Do not modify the elevating work platform without the prior written permission of the manufacturer. Installing additional equipment for placing tools or other materials on the platform, pedal plate or guardrail will increase the weight of the platform and the surface area of the platform or increase the load.
- 19) Do not modify or damage any parts that may affect the safety and stability of the vehicle.
- 20) Key parts that affect the vehicle's stability may not be replaced with parts of different weights or specifications.
- 21) Do not place the ladder or scaffolding in the platform or against any part of the vehicle.
- 22) Only tools and materials that are evenly distributed and can be safely moved by people on the platform can be transported.
- 23) Do not operate the vehicle on a moving surface or on a vehicle.
- 24) Make sure all tires are in good conditions and the nuts are properly tightened.
- 25) The ambient temperature in which the vehicle is operated is $-25^{\circ}\text{C} \sim 40^{\circ}\text{C}$.
- 26) The ambient relative humidity in which the vehicle is operated shall not exceed 90% (at 25°C).
- 27) The allowable fluctuation of the vehicle's supply voltage is $\pm 10\%$.

1.9 Risk of Crushing

- 1) Do not place arms, hands, or fingers in any position where there is a hazard of potential

crushing.

- When the machine is being operated from the ground using the control unit, use good judgment and carefully plan the travel path of the machine and boom. Keep a safe distance between the operator, machine and any fixed objects, walls, or buildings.

1.10 Risk of Operating on Slopes

Do not drive the vehicle on a slope that exceeds the vehicle's slope and side slope ratings. The slope rating applies to the vehicle that is in the retracted state.

Item \ Model	Along the boom direction	Vertical to the boom
Maximum working allowable angle	4.5 °	4.5 °

Warning

When the vehicle is going downhill, select the medium speed mode (turtle) or the slow speed mode (snail) set at the upper control!

1.11 Risk of Falling

- During operation, the personnel on the platform must wear the full body safety device and secure it with a seat belt hook to the approved rope attachment point. Only one hook can be tied to each rope attachment point.
- Do not sit, stand or climb on the guardrail of the platform. Always stand on the platform floor firmly.



- After the platform is lifted, the operator may not climb down the boom.
- Keep the platform floor free of debris.
- Lower the platform entry lifting rod or close the entry door before operating.
- Do not operate the vehicle if the guardrail is not installed properly or the entrance door fails to guarantee safe operation.
- Do not enter or exit the platform unless the vehicle is in the telescoped state.

1.12 Risk of Collision

- When starting or operating the vehicle, pay attention to the blind spots within the line of sight.
- When rotating the turntable, pay attention to the position of the boom and the tail of the turntable.
- Check the work area to avoid obstacles or other possible hazards.



- When holding onto the platform guardrail, be careful of the risk of crushing.
- Lower the boom when there are no people or obstacles in the area underneath.



- Limit the drive speed according to the ground conditions, congestion levels, slope, personnel location and any other factors that may cause a collision.
- It is not allowed to operate the machine on any crane or moving overhead vehicle route unless the crane control unit has

been locked and/or precautions have been taken to prevent any potential collision.

- 8) When operating the machine, avoid any dangerous behaviors.
- 9) Users must abide by user rules, workplace rules and government rules regarding the use of personal protective equipment.
- 10) The direction arrows of the drive and steering function of the upper control box should be noted.

1.13 Risk of Component Damage

- 1) Do not use any battery or charger greater than 12 V to start the engine.
- 2) Do not use the machine as the ground wire during welding.
- 3) Do not use the machine in the place where there may be magnetic field.

1.14 Risk of Explosion and Fire

- 1) Do not operate the vehicle where it is dangerous or where flammable or explosive gases or particles may be present.
- 2) Do not start up the engine if liquefied petroleum gas (LPG), gasoline, diesel, or other explosive substances are present.
- 3) Do not refuel the machine when the engine is running.
- 4) Only refuel the machine in open and well-ventilated places far away from sparks, open flames, burning cigarettes, etc.

1.15 Risk of Machine Damage

- 1) Do not operate a machine that is damaged or faulty.
- 2) Before each work shift, thoroughly perform the pre-operation inspection against the vehicle and test all functions. A damaged or faulty vehicle should be immediately tagged out and stopped.
- 3) Make sure all maintenance operations have

been performed as specified in this manual.

- 4) Make sure all decals are properly positioned and easily identifiable.
- 5) Make sure this manual is stored in the manual box on the platform.

1.16 Risk of Bodily Injury

- 1) Do not operate the vehicle with hydraulic oil leaks, which may penetrate when under pressure or burn your skin.
- 2) Incorrect contact with any component under the cover may cause serious injury. Only qualified authorized service personnel can access the compartment. It is recommended that the operator perform the inspection only during the pre-operation inspection. All compartments must be closed and locked during operation.
- 3) Always operate the machine in a well-ventilated area to avoid of carbon monoxide poisoning.

1.17 Battery Safety

Risk of Burns

- 1) The battery contains acidic substances. Wear protective clothing and goggles when maintaining the battery.



- 2) Avoid spilling or touching the acid in the battery. Soda and water can be used to neutralize the spilled battery acid.
- 3) When the vehicle is not operated for a long time, turn off the main power switch.

Risk of explosion



- 1) Sparks, flames and lit cigarettes are

prohibited from getting close to the battery. The battery can release explosive gases.

the tires immediately.

- 2) Do not touch the battery terminals or cable clamps with tools that may cause sparks.

Risk of Electric Shock/Burn

- 1) Avoid electric shock due to contact with battery terminals. Remove all rings, watches and other accessories.

1.18 Locked After Each Use

- 1) Choose a safe parking location that can be a solid, flat surface without obstructions or heavy traffic.
- 2) Telescope the boom and lower the platform.
- 3) Rotate the turntable to make the boom located between non-steering wheels.
- 4) Turn the key switch to the "OFF" position and remove the key to avoid any unauthorized use.


1.19 Check Tires and Wheels

This check item is conducted every 250 hours or once per quarter, whichever comes first.

Keeping tires and hubs in a good condition is critical for safe operation and good performance. Failure of the tires and hubs may cause the platform to tilt. If such failure is not found and repaired in time, it will also cause damage to platform parts.


- 1) Check treads and sides of tires for scratches, cracks, punctures, and other abnormal wear.
- 2) Check if the wheels are damaged, bent or cracked.
- 3) Check whether or not the sealing screws for tires are missing. If missing screws, if there is slight or no leakage of fillers, and no significant deformation is found for the tire body, and users can knock in screws which are slightly larger than the diameter (about 5mm/2in) of the vent hole with a hammer. If leakage of a large quantity of filler is found, and the tire body deforms significantly, lower the platform and replace

Chapter 2 Legend




No.	Name	No.	Name
1	File Box	7	Jib
2	Foot Switch	8	Base Boom Section
3	Lifting Rod	9	Tower Boom Section
4	Lanyard Fixing Point	10	Lower Control Box
5	Platform	11	Steering Wheel
6	Upper Control Box	12	Non-Steering Wheel


Chapter 3 Decals

Label


1-2534000039




2-2534002019



3-2534000045



4-2534002237




5-2534000043



6-2534000004




7-2534000048




8-2534000026



9-2534000047



10-2534000368



11-2534001807/0732

AR14J
AR16J

12-2534001749

LGMG

13-2534000042




14-2534000017



15-2534000248




16-2534000036




17-2534000063




18-2534000035




19-2534000037



20-2534000119




21-2534000247



22-2534000024



23-2534002518



24-2534000786




25-2534001377



26-2534000051




27-2534000053



28-2534000050



29-2534000052



30-2534000056

4 × 4

31-2534000325




32-2534001808/0508

AR14J
AR16J

Code	Number	Name
1	2534000039	Sign for caution of tilting
2	2534002019	Sign for lanyard fixed point
3	2534000045	Tire description sign
4	2534002237	Wheel load sign
5	2534000043	Anti-crush hazard sign
6	2534000004	Warning sign for explosion and burns
7	2534000048	Electric shock hazard sign
8	2534000026	Reading instructions
9	2534000047	Warning sign for fire prohibition
10	2534000368	Group LOGO-Right
11	2534001807/0732	Model signs-AR14J-AR16J
12	2534001749	Group LOGO-LGMG
13	2534000042	Sign for caution of falling
14	2534000017	Sign for lanyard fixed point
15	2534000248	Anti-scratch sticker
16	2534000036	Caution sign for lifting and lowering the middle guardrail
17	2534000063	Sign for caution of tipping up and down the slope
18	2534000035	Rated load of platform
19	2534000037	Sign for maximum hand power
20	2534000119	Sign for reading instructions
21	2534000247	Electric shock hazard sign
22	2534000024	Warning signs
23	2534002518	Machine nameplate
24	2534000786	107 dB
25	2534001377	Hydraulic oil level
26	2534000051	arrow sign
27	2534000053	arrow sign
28	2534000050	arrow sign
29	2534000052	arrow sign
30	2534000056	Driving form
31	2534000325	Warning signs
32	2534001808/0508	Model sign-AR14J/AR16J

Label



1-2534000362



2-2534000024



3-2534000363



4-2534002237




5-2534000045




6-2534001807/0732

AR14J
AR16J


7-2534000367




8-2534002019



9-2534000039




10-2534000247



11-2534000011




12-2534000048



13-2534000041



14-2534001995



15-2534000177



Code	Number	Name
1	2534000362	Reflective sticker
2	2534000024	Warning signs
3	2534000363	Reflective sticker
4	2534002237	Wheel load
5	2534000045	Caution signs of replaced tire
6	2534001807/0732	Model sign
7	2534000367	Group-LOGO-left
8	2531002019	Sign for lanyard fixed point
9	2534000039	Anti-Rollover
10	2534000247	Electric shock hazard sign
11	2534000011	In-box maintenance sign
12	2534000048	Defend electric shock hazard
13	2534000041	Warning sign for stay away from machine
14	2534001995	Label-Hydraulic oil
15	2534000177	Label-Fuel tank

Chapter 4 Specification

AR14J Specifications
4.1 Performance Specifications

Item	Specification	Item	Specification
Rated load (kg)	230	Gradeability	45%
Maximum number of people	2	Turntable rotation by one circle (S)	82-92
Maximum working height (m)	16.09	Boom lifting (S)	35-45
Maximum platform height (m)	14.09	Boom lowering (S)	30-40
Maximum horizontal extension (m)	7.67	Tower boom lifting (S)	25-35
Maximum span height (m)	7.56	Tower boom lowering (S)	26-40
Vehicle speed (in the telescoped state) (km/h)	7.2	Telescopic boom extended (S)	20-30
Vehicle speed (in the lifted state) (km/h)	0.8	Telescopic boom telescoped (S)	20-30
Vehicle climbing speed(in the telescoped state) (km/h)	>2	Small arm lifting (S)	30-50
Vehicle climbing speed(in the lifted state) (km/h)	≤0.8	Small arm lowering (S)	20-35
Minimum turning radius (inner wheel) (m)	1.94	Platform rotation (S)	13-26
Minimum turning radius (outer wheel) (m)	4.41	Maximum allowable tilt angle	4.5°

4.2 Dimensions

Item	Specification	Item	Specification
Vehicle length (m)	6.83	Track width (mm)	1981.5
Vehicle width (m)	2.31	Wheelbase (mm)	2059
Vehicle height (m)	2.17	Ground clearance (in the telescoped state) (m)	0.36
Working platform size (L×W) (m)	1.8×0.76	Tire specification (diameter × width)(mm)	315/55D20
Vehicle weight (kg)	7070		

4.3 Engine

Item	Specifications/Contents	Item	Specifications/Contents
Model	V2403-M-DI-ET04e	Number of cylinder	4
Rated power (KW)	36	Type	In-line, water-cooling and four-stroke
Rated speed (r/min)	2600	Maximum torque (N.m)/speed (r/min)	158.6/1600
Displacement (ml)	2434	Emission standard	GB 20891-2014 China Phase

			III
--	--	--	-----

4.4 Hydraulic system

Item	Specifications/Contents	
Type	Open function system and closing walking system	
Function pump	11ml/r	
Drive pump	46 ml/r; charge pump 13.9ml/r	
Drive motor	25 ml/r	
System pressure (bar/psi)	Walking	300
	Charge pump	19.5
	Function pump	235

4.5 Swing Mechanism

Item		Specification/content
Swing motor	Displacement (ml/r)	160
	Output torque(Nm)	8729

4.6 Electric System

Item	Specifications
Model	6-QW-120B
Weight(Kg)	30
Output voltage(V)	12
20 hours AH	120

4.7 Oil Capacity

Item	Specifications
Hydraulic oil (No.46)(L)	130 (replacement of oil)
Engine oil (L)	9.5
Diesel(L)	65
Reducer (4) 80-90/w(L)	0.68*4

Note: When hydraulic oil and diesel are filled, it is necessary to use the corresponding hydraulic oil and diesel according to operating environment and temperature. Refer to the following tables:

Item	Condition	Oil viscosity brand	Remarks
Hydraulic oil(L)	The lowest temperature > -33°C	L-HV46 Low temperature hydraulic oil	Recommended chevron brand
	-39°C < The lowest temperature ≤ -33°C	L-HS46 Ultra low temperature hydraulic oil	
	The lowest temperature ≤ -39°C	10# Aviation hydraulic oil	
Driving Reducer oil	30 ° C < The lowest temperature	85W/140	GB13895-2018
	-10 ° C < The lowest temperature < 30 ° C	85W/90	
	-30 ° C < The lowest temperature < -10 ° C	80W/90	
	The lowest temperature < -30 ° C	75W	
Engine oil(L)	Working temperature:-20°C ~ 40°C	CH-4/15W-40	/
	Working temperature:-25°C ~ 30°C	CH-4/10W-30	
	Working temperature:-30°C ~ 30°C	CH-4/5W-30	
	Working temperature:-35°C ~ 20°C	CH-4/0W-20	
Diesel (L)	Working temperature ≥ 4 °C,	Diesel 0#	
	Working temperature ≥ -5 °C,	Diesel -10#	
	Working temperature ≥ -14 °C,	Diesel -20#	
	Working temperature ≥ -29 °C,	Diesel -35#	

AR14J Specifications (A1408JNKGH21)
4.1 Performance Specifications

Item	Specification	Item	Specification
Rated load (kg)	230	Gradeability	45%
Maximum number of people	2	Turntable rotation by one circle(S)	82-92
Maximum working height (m)	16.09	Boom lifting (S)	35-45
Maximum platform height (m)	14.09	Boom lowering (S)	30-40
Maximum horizontal extension (m)	7.67	Tower boom lifting (S)	25-35
Maximum span height (m)	7.56	Tower boom lowering (S)	26-40
Vehicle speed (in the telescoped state) (km/h)	7.2	Telescopic arm extended(S)	20-30
Vehicle speed (in the lifted state) (km/h)	0.8	Telescopic arm telescoped (S)	20-30
Vehicle climbing speed(in the telescoped state) (km/h/mpH)	>2	Small arm lifting (S)	30-50
Vehicle climbing speed(in the lifted state) (km/h/mpH)	≤0.8	Small arm lowering (S)	20-35
Minimum turning radius (inner wheel) (m)	1.94	Platform rotation (S)	13-26
Minimum turning radius (outer wheel) (m)	4.41	Maximum allowable tilt angle	4.5°

4.2 Dimensions

Item	Specification	Item	Specification
Vehicle length (m)	6.83	Track width (mm)	1981.5
Vehicle width (m)	2.31	Wheelbase (mm)	2059
Vehicle height (m)	2.17	Ground clearance (in the telescoped state) (m)	0.36
Working platform size (L×W) (m)	1.8×0.76	Tire specification (diameter × width)(mm)	315/55D20
Vehicle weight (kg)	7070		

4.3 Engine System

Item	Specifications/Contents	Item	Specifications/Contents
Model	V2403-M-DI-ET04	Number of cylinder	4
Rated power (/KW)	36	Type	In-line, water-cooling and four-stroke
Rated speed (r/min)	2,600	Maximum torque (N.m)/speed (r/min)	158.6/1,600

Displacement (ml)	2,434	Emission standard	GB 20891-2014 China Phase III
-------------------	-------	-------------------	----------------------------------

4.4 Hydraulic System

Item	Specifications/Contents	
Type	Open function system and closing walking system	
Function pump	11ml/r	
Walking pump	46 ml/r; charge pump 13.9ml/r	
Walking motor	25 ml/r	
System pressure (bar)	Walking	300
	Charge pump	19.5
	Function pump	235

4.5 Swing Mechanism

Item	Specification/content	
Swing motor	Displacement (ml/r)	475
	Output torque(Nm)	8729

4.6 Electric System

Item	Specifications
Model	6-QW-120B
Weight(Kg)	30
Output voltage(V)	12
20 hours AH	120

4.7 Oil Capacity

Item	Specifications
Hydraulic oil (No.46)(L)	130 (replacement of oil)
Engine oil (L)	9.5
Diesel(L)	65
Reducer (4) 80-90/w(L)	0.68*4

Note: When hydraulic oil and diesel are filled, it is necessary to use the corresponding hydraulic oil and diesel according to operating environment and temperature. Refer to the following tables:

Item	Condition	Oil viscosity brand	Remarks
Hydraulic oil(L)	The lowest temperature > -33°C	L-HV46 Low temperature hydraulic oil	Recommended chevron brand
	-39°C < The lowest temperature ≤ -33°C	L-HS46 Ultra low temperature hydraulic oil	
	The lowest temperature ≤ -39°C	10# Aviation hydraulic oil	
Driving Reducer oil	30 ° C < The lowest temperature	85W/140	GB13895-2018
	-10 ° C < The lowest temperature < 30 ° C	85W/90	
	-30 ° C < The lowest temperature < -10 ° C	80W/90	
	The lowest temperature < -30 ° C	75W	
Engine oil(L)	Working temperature:-20°C ~ 40°C	CH-4/15W-40	/
	Working temperature:-25°C ~ 30°C	CH-4/10W-30	
	Working temperature:-30°C ~ 30°C	CH-4/5W-30	
	Working temperature:-35°C ~ 20°C	CH-4/0W-20	
Diesel (L)	Working temperature ≥ 4 °C,	Diesel 0#	
	Working temperature ≥ -5 °C,	Diesel -10#	
	Working temperature ≥ -14 °C,	Diesel -20#	
	Working temperature ≥ -29 °C,	Diesel -35#	

AR16J (A1609JNKGH20)

4.1 Performance Specifications

Item	Specification	Item	Specification
Rated load (kg)	230	Gradeability	45%
Maximum number of people	2	Turntable rotation by one circle(S)	82-92
Maximum working height (m)	17.7	Boom lifting (S)	35-45
Maximum platform height (m)	15.7	Boom lowering (S)	30-40
Maximum horizontal extension (m)	9.39	Tower boom lifting (S)	25-35
Maximum span height (m)	7.56	Tower boom lowering (S)	26-40
Vehicle speed (in the telescoped state) (km/h/mpH)	7.2	Telescopic arm extended(S)	20-30
Vehicle speed (in the lifted state) (km/h/mpH)	0.8	Telescopic arm telescoped (S)	20-30
Vehicle climbing speed(in the telescoped state) (km/h/mpH)	> 2	Small arm lifting (S)	30-50
Vehicle climbing speed(in the lifted state) (km/h/mpH)	≤ 0.8	Small arm lowering (S)	20-35
Minimum turning radius (inner wheel) (m)	1.94	Platform rotation (S)	13-26
Minimum turning radius (outer wheel) (m)	4.41	Maximum allowable tilt angle	4.5°

4.2 Dimensions

Item	Specification	Item	Specification
Vehicle length (m)	7.56	Track width (mm)	1981.5
Vehicle width (m)	2.31	Wheelbase (mm)	2059
Vehicle height (m)	2.17	Ground clearance (in the telescoped state) (m)	0.36
Working platform size (L×W) (m)	1.83×0.76	Tire specification (diameter × width)(mm)	315/55D20
Vehicle weight (kg)	8000		

4.3 Engine System

Item	Specifications/Contents	Item	Specifications/Contents
Model	V2403-M-DI-ET04	Number of cylinder	4
Rated power (/KW)	36	Type	In-line, water-cooling and four-stroke

Rated speed (r/min)	2,600	Maximum torque (N.m)/speed (r/min)	158.6/1,600
Displacement (ml)	2,434	Emission standard	GB 20891-2014 China Phase III

4.4 Hydraulic System

Item	Specifications/Contents	
Type	Open function system and closing walking system	
Function pump	11ml/r	
Walking pump	46 ml/r; charge pump 13.9ml/r	
Walking motor	25 ml/r	
System pressure (bar)	Walking	300
	Charge pump	19.5
	Function pump	235

4.5 Swing Mechanism

Item	Specification/content	
Swing motor	Displacement (ml/r)	160
	Output torque(Nm)	8729

4.6 Electric System

Item	Specifications
Model	6-QW-120B
Weight(Kg)	30
Output voltage(V)	12
20 hours AH	120

4.7 Oil Capacity

Item	Specifications
Hydraulic oil (No.46)(L)	130 (replacement of oil)
Engine oil (L)	9.5
Diesel(L)	65
Reducer (4) 80-90/w(L)	0.68*4

Note: When hydraulic oil and diesel are filled, it is necessary to use the corresponding hydraulic oil and diesel according to operating environment and temperature. Refer to the following tables:

Item	Condition	Oil viscosity brand	Remarks
Hydraulic oil(L)	The lowest temperature > -33°C	L-HV46 Low temperature hydraulic oil	Recommended chevron brand
	-39°C < The lowest temperature ≤ -33°C	L-HS46 Ultra low temperature hydraulic oil	
	The lowest temperature ≤ -39°C	10# Aviation hydraulic oil	
Driving Reducer oil	30 ° C < The lowest temperature	85W/140	GB13895-2018
	-10 ° C < The lowest temperature < 30 ° C	85W/90	
	-30 ° C < The lowest temperature < -10 ° C	80W/90	
	The lowest temperature < -30 ° C	75W	
Engine oil(L)	Working temperature:-20°C ~ 40°C	CH-4/15W-40	/
	Working temperature:-25°C ~ 30°C	CH-4/10W-30	
	Working temperature:-30°C ~ 30°C	CH-4/5W-30	
	Working temperature:-35°C ~ 20°C	CH-4/0W-20	
Diesel (L)	Working temperature ≥ 4 °C,	Diesel 0#	
	Working temperature ≥ -5 °C,	Diesel -10#	
	Working temperature ≥ -14 °C,	Diesel -20#	
	Working temperature ≥ -29 °C,	Diesel -35#	

AR16J(A1609JNKGH21)
4.1 Performance Specifications

Item	Specification	Item	Specification
Rated load (kg)	230	Gradeability	45%
Maximum number of people	2	Turntable rotation by one circle(S)	80-90
Maximum working height (m)	17.7	Boom lifting (S)	35-45
Maximum platform height (m)	15.7	Boom lowering (S)	30-40
Maximum horizontal extension (m)	9.39	Tower boom lifting (S)	25-35
Maximum span height (m)	7.56	Tower boom lowering (S)	26-40
Vehicle speed (in the telescoped state) (km/h)	7.2	Telescopic arm extended(S)	20-30
Vehicle speed (in the lifted state) (km/h)	0.8	Telescopic arm telescoped (S)	20-30
Minimum turning radius (inner wheel) (m)	1.93	Small arm lifting (S)	30-45
Minimum turning radius (outer wheel) (m)	4.39	Small arm lowering (S)	20-35
Maximum allowable tilt angle	4.5°	Platform rotation (S)	8-16

4.2 Dimensions

Item	Specification	Item	Specification
Vehicle length (m)	7.56	Track width (mm)	1981.5
Vehicle width (m)	2.31	Wheelbase (mm)	2042.5
Vehicle height (m)	2.17	Ground clearance (in the telescoped state) (m)	0.36
Working platform size (L×W) (m)	1.8×0.76	Tire specification (diameter × width)(mm)	315/55D20
Vehicle weight (kg)	8000		

4.3 Engine System

Item	Specifications/Contents	Item	Specifications/Contents
Model	V2403-M-DI-ET04	Number of cylinder	4
Rated power (/KW)	36	Type	In-line, water-cooling and four-stroke
Rated speed (r/min)	2,600	Maximum torque (N.m)/speed (r/min)	158.6/1,600
Displacement (ml)	2,434	Emission standard	GB 20891-2014 China Phase III

4.4 Hydraulic System

Item	Specifications/Contents	
Type	Open function system and closing walking system	
Function pump	8 ml/r	
Walking pump	46 ml/r; charge pump 13.9ml/r	
Walking motor	25 ml/r	
System pressure (bar)	Walking	300
	Charge pump	28.3
	Function pump	235

4.5 Swing Mechanism

Item	Specification/content	
Swing motor	Displacement (ml/r)	475
	Output torque(Nm)	820

4.6 Electric System

Item	Specifications
Model	6-QW-120B
Weight(Kg)	30
Output voltage(V)	12

4.7 Oil Capacity

Item	Specifications
Hydraulic oil (No.46)(L)	130 (replacement of oil)
Engine oil (L)	9.5
Diesel(L)	65
Reducer (4) 80-90/w(L)	0.68*4

Note: When hydraulic oil and diesel are filled, it is necessary to use the corresponding hydraulic oil and diesel according to operating environment and temperature. Refer to the following tables:

Item	Condition	Oil viscosity brand	Remarks
Hydraulic oil(L)	The lowest temperature > -33°C	L-HV46 Low temperature hydraulic oil	Recommended chevron brand
	-39°C < The lowest temperature ≤ -33°C	L-HS46 Ultra low temperature hydraulic oil	
	The lowest temperature ≤ -39°C	10# Aviation hydraulic oil	
Driving Reducer oil	30 ° C < The lowest temperature	85W/140	GB13895-2018
	-10 ° C < The lowest temperature < 30 ° C	85W/90	
	-30 ° C < The lowest temperature < -10 ° C	80W/90	
	The lowest temperature < -30 ° C	75W	
Engine oil(L)	Working temperature:-20°C ~ 40°C	CH-4/15W-40	/
	Working temperature:-25°C ~ 30°C	CH-4/10W-30	
	Working temperature:-30°C ~ 30°C	CH-4/5W-30	
	Working temperature:-35°C ~ 20°C	CH-4/0W-20	
Diesel (L)	Working temperature ≥ 4 °C,	Diesel 0#	
	Working temperature ≥ -5 °C,	Diesel -10#	
	Working temperature ≥ -14 °C,	Diesel -20#	
	Working temperature ≥ -29 °C,	Diesel -35#	

4.1 Performance Specifications

Item	Specification	Item	Specification
Rated load (kg)	230	Gradeability	45%
Maximum number of people	2	Turntable rotation by one circle(S)	82-92
Maximum working height (m)	17.7	Boom lifting (S)	35-45
Maximum platform height (m)	15.7	Boom lowering (S)	30-40
Maximum horizontal extension (m)	9.39	Tower boom lifting (S)	25-35
Maximum span height (m)	7.56	Tower boom lowering (S)	26-40
Vehicle speed (in the telescoped state) (km/h)	7.2	Telescopic arm extended(S)	20-30
Vehicle speed (in the lifted state) (km/h)	0.8	Telescopic arm telescoped (S)	20-30
Vehicle climbing speed(in the telescoped state) (km/h)	> 0.2	Small arm lifting (S)	30-50
Vehicle climbing speed(in the lifted state) (km/h)	≤0.8	Small arm lowering (S)	20-35
Minimum turning radius (inner wheel) (m)	1.94	Platform rotation (S)	13-26
Minimum turning radius (outer wheel) (m)	4.41	Maximum allowable tilt angle	4.5

4.2 Dimensions

Item	Specification	Item	Specification
Vehicle length (m)	7.56	Track width (mm)	1981.5
Vehicle width (m)	2.31	Wheelbase (mm)	2059
Vehicle height (m)	2.17	Ground clearance (in the telescoped state) (m)	0.36
Working platform size (L×W) (m)	1.8×0.76	Tire specification (diameter × width)(mm)	315/55D20
Vehicle weight (kg)	8000		

4.3 Engine System

Item	Specifications/Contents	Item	Specifications/Contents
Model	V2403-M-DI-ET04	Number of cylinder	4
Rated power (/KW)	36	Type	In-line, water-cooling and four-stroke
Rated speed (r/min)	2,600	Maximum torque (N.m)/speed (r/min)	158.6/1,600
Displacement (ml)	2,434	Emission standard	GB 20891-2014 China Phase III

4.4 Hydraulic System

Item	Specifications/Contents	
Type	Open function system and closing walking system	
Function pump	11 ml/r	
Walking pump	46 ml/r; charge pump 13.9ml/r	
Walking motor	25 ml/r	
System pressure (bar)	Walking	300
	Charge pump	19.5
	Function pump	235

4.5 Swing Mechanism

Item		Specification/content
Swing motor	Displacement (ml/r)	160
	Output torque(Nm)	8729

4.6 Electric System

Item	Specifications
Model	6-QW-120B
Weight(Kg)	30
Output voltage(V)	12

4.7 Oil Capacity

Item	Specifications
Hydraulic oil (No.46)(L)	130 (replacement of oil)
Engine oil (L)	9.5
Diesel(L)	65
Reducer (4) 80-90/w(L)	0.68*4

Note: When hydraulic oil and diesel are filled, it is necessary to use the corresponding hydraulic oil and diesel according to operating environment and temperature. Refer to the following tables:

Item	Condition	Oil viscosity brand	Remarks
Hydraulic oil(L)	The lowest temperature > -33°C	L-HV46 Low temperature hydraulic oil	Recommended chevron brand
	-39°C < The lowest temperature ≤ -33°C	L-HS46 Ultra low temperature hydraulic oil	
	The lowest temperature ≤ -39°C	10# Aviation hydraulic oil	
Driving Reducer oil	30 ° C < The lowest temperature	85W/140	GB13895-2018
	-10 ° C < The lowest temperature < 30 ° C	85W/90	
	-30 ° C < The lowest temperature < -10 ° C	80W/90	
	The lowest temperature < -30 ° C	75W	
Engine oil(L)	Working temperature:-20°C ~ 40°C	CH-4/15W-40	/
	Working temperature:-25°C ~ 30°C	CH-4/10W-30	
	Working temperature:-30°C ~ 30°C	CH-4/5W-30	
	Working temperature:-35°C ~ 20°C	CH-4/0W-20	
Diesel (L)	Working temperature ≥ 4 °C,	Diesel 0#	
	Working temperature ≥ -5 °C,	Diesel -10#	
	Working temperature ≥ -14 °C,	Diesel -20#	
	Working temperature ≥ -29 °C,	Diesel -35#	

4.1 Performance Specifications

Item	Specification	Item	Specification
Rated load (kg)	230	Gradeability	45%
Maximum number of people	2	Turntable rotation by one circle(S)	120-150/ 240-300
Maximum working height (m)	20.8	Boom lifting (S)	60-65
Maximum platform height (m)	18.8	Boom lowering (S)	65-70
Maximum horizontal extension (m)	12.1	Tower boom lifting (S)	40-45
Maximum span height (m)	8.2	Tower boom lowering (S)	45-50
Vehicle speed (in the telescoped state) (km/h)	4.8	Telescopic arm extended(S)	40-45
Vehicle speed (in the lifted state) (km/h)	1.1	Telescopic arm telescoped (S)	45-50
Minimum turning radius (inner wheel) (m)	2.5	Small arm lifting (S)	68-73
Minimum turning radius (outer wheel) (m)	5.5	Small arm lowering (S)	77-82
Maximum allowable tilt angle	4.5	Platform rotation (S)	8-12

4.2 Dimensions

Item	Specification	Item	Specification
Vehicle length (m)	9.36	Track width (mm)	2130
Vehicle width (m)	2.49	Wheelbase (mm)	2510
Vehicle height (m)	2.56	Ground clearance (in the telescoped state) (m)	0.395
Working platform size (L×W) (m)	2.44 × 0.91	Tire specification (diameter × width)(mm)	315/55D20
Vehicle weight (kg)	10000		

4.3 Engine System

Item	Specifications/Contents	Item	Specifications/Contents
Model	Deutz D2.9L4	Number of cylinder	4
Rated power (KW)	36.4	Type	In-line, water-cooling and four-stroke
Rated speed (r/min)	2,600	Maximum torque (N.m)/speed (r/min)	260/1,600
Displacement (ml)	2,900	Emission standard	GB 20891-2014 China PhaseIV

4.4 Hydraulic System

Item	Specifications/Contents
------	-------------------------

Type	Open function system and closing walking system	
Function pump	18ml/r	
Walking pump	45.1 ml/r	
Walking motor	38 ml/r	
System pressure (bar)	Walking	300
	Charge pump	20
	Function pump	250

4.5 Swing Mechanism

Item		Specification/content
Swing motor	Displacement (ml/r)	60
	Output torque(Nm)	1690

4.6 Electric System

Item	Specifications
Model	6-QW-120B
Weight(Kg)	30
Output voltage(V)	12

4.7 Oil Capacity


Item	Specifications
Hydraulic oil (No.46)(L)	120 (replacement of oil)
Engine oil (L)	9.5
Diesel(L)	110
Reducer (4) 80-90/w(L)	0.68*4

Note: When hydraulic oil and diesel are filled, it is necessary to use the corresponding hydraulic oil and diesel according to operating environment and temperature. Refer to the following tables:

Item	Condition	Oil viscosity brand	Remarks
Hydraulic oil(L)	The lowest temperature > -33°C	L-HV46 Low temperature hydraulic oil	Recommended chevron brand
	-39°C < The lowest temperature ≤ -33°C	L-HS46 Ultra low temperature hydraulic oil	
	The lowest temperature ≤ -39°C	10# Aviation hydraulic oil	
Driving Reducer oil	30 ° C < The lowest temperature	85W/140	GB13895-2018
	-10 ° C < The lowest temperature < 30 ° C	85W/90	
	-30 ° C < The lowest temperature < -10 ° C	80W/90	
	The lowest temperature < -30 ° C	75W	
Engine oil(L)	Working temperature:-20°C ~ 40°C	CH-4/15W-40	/
	Working temperature:-25°C ~ 30°C	CH-4/10W-30	
	Working temperature:-30°C ~ 30°C	CH-4/5W-30	
	Working temperature:-35°C ~ 20°C	CH-4/0W-20	
Diesel (L)	Working temperature ≥ 4 °C,	Diesel 0#	
	Working temperature ≥ -5 °C,	Diesel -10#	
	Working temperature ≥ -14 °C,	Diesel -20#	
	Working temperature ≥ -29 °C,	Diesel -35#	

Chapter 5 Control Unit

5.1 Lower Control Box




No.	Name	No.	Name
1	Emergency Stop Switch	10	Turntable Swing Switch
2	Key Switch	11	Tower Boom up/down Switch
3	Reserve	12	Emergency Descent Button Switch
4	Engine Idle Speed (Rpm) Selector Switch	13	Platform Swing Button Switch
5	Tower Boom up/down Switch	14	Platform Leveling Switch
6	Engine Warm-up Switch	15	Function Enable Switch
7	Engine Start Button Switch	16	Hinge
8	Base Boom up/down Switch	17	Display
9	Base boom extend/retract Switch		

The functional description of the lower control box button switch is as follows:

Item	Button switch	Functional description	
Lower Control Box	Key Switch	When turning the key switch to the “Platform” position, the upper control box will be enabled. When turning the key switch to the “OFF” position, the vehicle will stop. Turn the key switch to the “Ground” position and the lower control box will be enabled.	
	Emergency Stop Button Switch	When pushing the red “Emergency Stop” button inward to the “OFF” position, all functions can be disabled. When each function control handle or button switch of the vehicle is enabled, all functions will not be enabled.	
		When pulling the red “Emergency Stop” button to the “ON” position, the vehicle can be operated and the warning light should flash.	
	Function Enable Switch	Do not press and hold the function enable dial switch, try to activate each boom and platform function button switch. The boom and platform functions will not be enabled.	
		When pressing and holding the function enable button and activating each boom and platform function button switch, the boom and platform functions should operate for a full cycle.	
	Engine Start Switch	Move the engine start switch to one side to start the engine.	
	Engine idle speed selector switch	Pull the idle speed selector switch to the turtle position, the engine starts the low idle speed; Pull the idle speed selector switch to the rabbit position, step on the foot switch and turn the handle, then the engine starts the high idle speed. After releasing the handle, the engine enters the low idle speed.	
	<ol style="list-style-type: none"> 1. Turn the key button switch to the lower control box. 2. Pull the red “Emergency Stop” button outward to the “ON” position. 3. Press and hold the enable button. 		
	Platform Swing Switch	 When moving the platform swing button switch to the right, the platform will rotate to the right. When moving the platform rotation button switch to the left, the platform will rotate to the left.	
	Turntable Swing Switch	 When turning the button switch to the right, the turntable will move to the right. When moving the button to the left, the turntable will move to the left.	
	Base Boom Lifting/Lowering Switch	 When pulling the button switch upward, the boom will be lifted. When pulling the button switch downward, the boom will be lowered. The lowering alarm should sound when the boom is lowered.	
	Base Boom Extending/Retracting Switch	 When pulling the button switch to the left, the boom will be extended. When pressing the button switch to the right, the boom will be telescoped.	
	Tower boom section lifting/lowering Switch	 When pulling the button switch upward, the tower boom section will be lifted. When pulling the button switch downward, the tower boom section will be lowered. The lowering alarm should sound when the boom is lowered.	

<p>Jib up/down toggle switch</p>	 <p>Move the control handle up, the small arm will rise; Move the control handle down, the small arm will descend. When the small arm descends, the buzzer will sound;</p>
<p>Platform leveling toggle switch</p>	 <p>Move the switch up, the platform level will rise; move the switch down, the platform level will descend.</p>
<p>Emergency power switch</p>	 <p>If the main power source (engine) fails, please use the emergency power unit. Step on the foot switch to start the required functions while keeping the emergency power switch on.</p>
<p>Engine warm-up</p>	 <p>When starting at a low temperature, turn the toggle switch to the upper side to warm up the engine for 5-10s, and then pull back the toggle switch to stop warming up</p>

5.2 Upper Control Box




No.	Name	No.	Name
1	Indicator Light	9	Platform Swing Switch
2	Drive Enable Button Switch	10	Engine Start Switch
3	Emergency Stop Switch	11	Platform Leveling Switch
4	Drive/Steering Control Handle	12	Base Boom Lifting/Lowering and Turntable Swing Switch
5	Drive Speed Selector Switch	13	Horn Button
6	Tower Boom Section Lifting/Lowering Switch	14	Engine Idle Speed Selector Switch
7	Jib Lifting/Lowering Button	15	Emergency Descent Switch
8	Engine Warm-Up switch		

The functional description of the upper control box button switch is as follows:

Item	Button switch	Functional description	
Upper control box	Emergency Stop Button Switch	<p>When pushing the red “Emergency Stop” button inward to the “OFF” position, all functions can be disabled. When each function control handle or button switch of the vehicle is activated, all functions cannot be enabled.</p> <p>When the red "Emergency Stop" button is pulled to the “ON” position, the vehicle can be operated.</p>	
	Engine Start Switch	Move the engine start switch to one side to start the engine.	
	Foot Switch	The foot button switch may not be pressed and each function of the vehicle should be enabled. As a result, the vehicle function cannot be enabled.	
		When the foot button switch is pressed to activate each function control handle or button switch of the vehicle, all boom and platform functions should operate for a full cycle.	
	Horn Button	When the horn button is pressed, the horn will sound. When the horn button is released, the horn will stop ringing.	
	Function Enable Button Switch	Do not press and hold the function enable dial switch, try to activate each boom and platform function button switch. The boom and platform functions will not be enabled.	
		When pressing and holding the function enable button and activating each boom and platform function button switch, the boom and platform functions should operate for a full cycle.	
	<ol style="list-style-type: none"> 1. Turn the key button switch to the upper control box. 2. Pull the red “Emergency Stop” button outward to the “ON” position. 3. Press the foot button switch. 		
	Platform Swing Switch	 <p>When moving the platform Swing button switch to the right, the platform will rotate to the right. When moving the platform rotation button switch to the left, the platform will rotate to the left.</p>	
	Base boom Lifting/Lowering/ Extending/Retracting and Turntable Left/Right Rotation	 <p>When moving the control handle to the right, the turntable will move to the right. When moving the control handle to the left, the turntable will move to the left.</p>	
 <p>When moving the control handle up, the boom will be lifted. When moving the control handle downward, the boom will be lowered. The lowering alarm should sound when the boom is lowered.</p>			

		 <p>When pressing the lower side of the thumb rocker, the boom will be extended. When pressing the upper side of the thumb rocker, the boom will be telescoped.</p>
	Tower Boom Lifting/Lowering Switch	 <p>When pulling the button switch upward, the tower boom section will be lifted. When pulling the button switch downward, the tower boom section will be lowered. The lowering alarm should sound when the boom is lowered.</p>
	Jib Lifting/Lowering Switch	 <p>When pulling the button switch upward, the Jib will be lifted. When pulling the button switch downward, the Jib will be lowered.</p>
	Platform Leveling Switch	 <p>When pulling the platform leveling button switch upward, the platform level will be lifted. When pulling the platform leveling button switch downward, the platform level will drop.</p>
	Drive/Steering Control Handle	<p>When moving the control handle upward, the vehicle will drive forward. When moving the control handle downward, the vehicle will drive backward. When pressing the left side of the thumb rocker, the vehicle will turn to the left. When pressing the right side of the thumb rocker, the vehicle will turn to the right.</p>
	Drive Enable Switch	 <p>Press the foot switch and lower the boom to the telescoped position. Rotate the turntable until the boom moves over more than one non-steering wheel. As a result, the drive enable indicator should be lit at any position within the range shown in the figure. When moving the drive control handle to the center position, the drive function will not be enabled. When moving the drive enable button switch to one side and slowly moving the drive control handle away from the center position, the drive function should be enabled.</p> <p>Note: When operating the drive enable system, the vehicle can drive in the opposite direction of drive and steering control handle movement.</p>
	Engine Idle Speed Selector Switch	 <p>Pull the idle speed selector switch to the turtle position, the engine starts the low idle speed; Pull the idle speed selector switch to the rabbit position, step on the foot switch and turn the handle, then the engine starts the high idle speed. After releasing the handle, the engine enters the low idle speed.</p>
	Emergency power switch	 <p>If the main power source (engine) fails, please use the emergency power unit. Step on the foot switch to start the required functions while keeping the emergency power switch on.</p>

Upper Control Box (If equipped)



No.	Name	No.	Name
1	Horn Button	9	Emergency Stop Switch
2	Jib Lifting/Lowering Button	10	Engine Idle Speed Selector Switch
3	Base Boom Lifting/Lowering and Turntable Swing Switch	11	Indicator Light
4	Tower Boom Section Lifting/Lowering Switch	12	Drive Enable Button Switch
5	Drive Speed Selector Switch	13	Platform Swing Switch
6	Drive/Steering Control Handle	14	Platform Leveling Switch
7	Emergency Descent Switch	15	Engine Idle Speed Selector Switch
8	Engine Warm-Up switch	16	Engine Start switch

Item	Button switch	Functional description	
Upper control box	Emergency Stop Button Switch	<p>When pushing the red “Emergency Stop” button inward to the “OFF” position, all functions can be disabled. When each function control handle or button switch of the vehicle is activated, all functions cannot be enabled.</p> <p>When the red "Emergency Stop" button is pulled to the “ON” position, the vehicle can be operated.</p>	
	Engine Start Switch	Move the engine start switch to one side to start the engine.	
	Foot Switch	The foot button switch may not be pressed and each function of the vehicle should be enabled. As a result, the vehicle function cannot be enabled.	
		When the foot button switch is pressed to activate each function control handle or button switch of the vehicle, all boom and platform functions should operate for a full cycle.	
	Horn Button	When the horn button is pressed, the horn will sound. When the horn button is released, the horn will stop ringing.	
	<ol style="list-style-type: none"> 1. Turn the key button switch to the upper control box. 2. Pull the red “Emergency Stop” button outward to the “ON” position. 3. Press the foots button switch. 		
	Platform Swing Switch	 <p>When moving the platform Swing button switch to the right, the platform will rotate to the right. When moving the platform rotation button switch to the left, the platform will rotate to the left.</p>	
	Base boom Lifting/Lowering/ Extending/Retracting and Turntable Left/Right Rotation	 <p>When moving the control handle to the right, the turntable will move to the right. When moving the control handle to the left, the turntable will move to the left.</p>	
		 <p>When moving the control handle up, the boom will be lifted. When moving the control handle downward, the boom will be lowered. The lowering alarm should sound when the boom is lowered.</p>	
		 <p>When pressing the lower side of the thumb rocker, the boom will be extended. When pressing the upper side of the thumb rocker, the boom will be telescoped.</p>	
Tower Boom Lifting/Lowering Switch	 <p>When pulling the button switch upward, the tower boom section will be lifted. When pulling the button switch downward, the tower boom section will be lowered. The lowering alarm should sound when the boom is lowered.</p>		

<p>Jib Lifting/Lowering Switch</p>	 <p>When pulling the button switch upward, the Jib will be lifted. When pulling the button switch downward, the Jib will be lowered.</p>
<p>Platform Leveling Switch</p>	 <p>When pulling the platform leveling button switch upward, the platform level will be lifted. When pulling the platform leveling button switch downward, the platform level will drop.</p>
<p>Drive/Steering Control Handle</p>	<p>When moving the control handle upward, the vehicle will drive forward. When moving the control handle downward, the vehicle will drive backward. When pressing the left side of the thumb rocker, the vehicle will turn to the left. When pressing the right side of the thumb rocker, the vehicle will turn to the right.</p>
<p>Drive Enable Switch</p>	 <p>Press the foot switch and lower the boom to the telescoped position. Rotate the turntable until the boom moves over more than one non-steering wheel. As a result, the drive enable indicator should be lit at any position within the range shown in the figure. When moving the drive control handle to the center position, the drive function will not be enabled. When moving the drive enable button switch to one side and slowly moving the drive control handle away from the center position, the drive function should be enabled.</p> <p>Note: When operating the drive enable system, the vehicle can drive in the opposite direction of drive and steering control handle movement.</p>
<p>Engine Idle Speed Selector Switch</p>	 <p>Pull the idle speed selector switch to the turtle position, the engine starts the low idle speed; Pull the idle speed selector switch to the rabbit position, step on the foot switch and turn the handle, then the engine starts the high idle speed. After releasing the handle, the engine enters the low idle speed.</p>
<p>Emergency power switch</p>	 <p>If the main power source (engine) fails, please use the emergency power unit. Step on the foot switch to start the required functions while keeping the emergency power switch on.</p>

Chapter 6 Pre-Operation Inspection

6.1 No Operation Is Allowed Unless

You have understood and practiced the principles about safe operation of the vehicle in this manual.

- 1) Avoid dangerous situations.
- 2) Always perform a pre-operation inspection. You should understand pre-operation inspection before proceeding with the next step.
- 3) Check the workplace.
- 4) Always perform a pre-use functional test.
- 5) Use the vehicle only for its intended purpose.

6.2 Basic Principles

- 1) It is the operator's responsibility to perform pre-operation inspection and routine maintenance.
- 2) Pre-operation inspection is a very intuitive process that is performed by the operator before each shift. The purpose of the inspection is to determine if there is a significant problem with the vehicle before the operator performs a functional test.
- 3) Pre-operation inspection can also be used to determine if a routine maintenance procedure is necessary. The operator can only perform the routine maintenance items specified in this manual.
- 4) See the checklist on the next page and check each item.
- 5) In the event of any damage or any unauthorized changes different from the normal status, the vehicle should be marked and prohibited from putting into operation.
- 6) Only qualified authorized service technicians are allowed to maintain the vehicle according to the manufacturer's instructions. After the maintenance is completed, the operator must perform a pre-operation inspection again before continuing the functional test.
- 7) Regular maintenance inspections should

be performed by qualified authorized service technicians according to the manufacturer's specifications and the requirements listed in the responsibilities manual.

6.3 Pre-Operation Inspection

- 1) Make sure the manual is complete, easy to read, and stored in the manual box on the platform.
- 2) Make sure all decals are clear, legible, and in the right place. See the label section.
- 3) Check hydraulic oil for leakage and appropriate oil level. fill the oil as needed. See the "Maintenance" section.
- 4) Check the battery fluid for leakage and appropriate liquid level. Add the distilled water as needed. See the "Maintenance" section.
- 5) Check the following parts or areas for damage, improper installation, parts missing or unauthorized changes:
 - Electrical components, wires and cables
 - Valve block, hose, joint, cylinder
 - Hydraulic and fuel tank
 - Drive motor, Swing motor and drive hub
 - Boom wear pad
 - Tires and wheels
 - Limit button switch, tilt sensor and horn
 - Nuts, bolts and other fasteners
 - Platform overload components
 - Platform entrance lifting rod
 - Alarm light
 - Platform control handle
 - Engine and parts
- 6) Check the entire vehicle for the followings:
 - Crack in a weld or structural member
 - Dent or damage to the vehicle
 - Make sure all structural members and other critical components are complete,

and all associated fasteners and pins are in the right position and tightened.

- After completing the inspection, make sure all compartment covers are properly secured and locked.

Chapter 7 Workplace Inspection

7.1 No Operation Is Allowed Unless

You have understood and practiced the principles about safe operation of the vehicle in this manual.

- 1) Avoid dangerous situations.
- 2) Always perform a pre-operation inspection.
- 3) Check the workplace. You should understand pre-operation inspection before proceeding with the next step.
- 4) Always perform a pre-use functional test.
- 5) Use the vehicle only for its intended purpose.

7.2 Basic Principles

- 1) Workplace inspection will help the operator determine if the workplace is safe for operation of the vehicle. The operator should perform pre-operation inspection before moving the vehicle to the workplace.
- 2) It is the operator's responsibility to understand and remember the hazards in the workplace and to be aware of and avoid these hazards when moving, installing and operating the vehicle.

7.3 Workplace Inspection

Be aware of and avoid the following dangerous situations

- 1) Steep slope or cave
- 2) Protrusions, ground obstacles or debris
- 3) Inclined surface
- 4) Unstable or smooth surface
- 5) Overhead obstacles and high voltage wires
- 6) Dangerous location
- 7) Surface support that is not sufficient to withstand the full load applied by the vehicle
- 8) Wind and weather conditions
- 9) Unauthorized personnel
- 10) Other possible unsafe conditions

Chapter 8 Functional Test

8.1 No Operation Is Allowed Unless

You have understood and practiced the principles about safe operation of the vehicle in this manual.

- 1) Avoid dangerous situations.
- 2) Always perform a pre-operation inspection.
- 3) Check the workplace.
- 4) Always perform a pre-use functional test.
- 5) You should understand the functional test and inspection before proceeding with the next step.
- 6) Use the vehicle only for its intended purpose.

8.2 Basic Principles

- 1) Functional tests are used to detect faults before operating the vehicle.
- 2) The operator must follow the steps to test all the functions of the vehicle.
- 3) Do not use a malfunctioning vehicle. If a fault is found, the vehicle must be marked and stopped.
- 4) Only qualified authorized service technicians are allowed to maintain the vehicle according to the manufacturer's instructions.
- 5) After maintenance is completed, the operator must perform the pre-operation inspection and functional test again before operating the vehicle.

8.3 Functional Test

- 1) Choose a test place that is solid, level and free of obstacles.

8.4 Tests from the Lower Control Box

- 1) Turn the key button switch to the position of the lower control box.
- 2) Pull out the red "emergency stop" button to the "ON" position, and the warning light will begin to flash.

- 3) Refer to the "Operation Instructions" section to start the engine.

Test of emergency stop

- 1) Push the ground red "Emergency Stop" button inward to the "OFF" position.
- 2) Result: The engine is off and none of the functions work.
- 3) Pull the red emergency stop button to the "on" position to restart the engine.

Test of vehicle function

- 1) Do not press and hold the function enable button switch. Try to enable each boom and platform function button switch.

Result: No boom and platform function can be enabled.

- 2) Press and hold the function enable button and activate each boom and platform function button switch.

Result: The boom and platform functions should operate for a full cycle. When the boom is lowered, the lowering alarm (if equipped) should sound.

Test the Function of the Emergency Power Unit

 **Caution: Perform this step when the engine is off. In order to save battery energy, test each function in half a cycle.**

- Turn the key switch to the ground control and pull the red emergency stop button out to the "on" position.
- At the same time, press the emergency power unit switch to the on position and start each arm function switch.

Result: All boom functions are operational.

Inspect the Automatic Leveling of the Work Platform

- Start the engine from the ground.
- Press the function enable switch and use the platform leveling toggle switch to adjust the work platform to the horizontal position.

- Raise and descend the boom through a full cycle.

Result: The work platform is always level.

8.5 Tests from the Upper Control Box

Test the Emergency Stop

- Push the platform red "Emergency Stop" button to the "OFF" position.
- Enter the platform to pull out the red "emergency stop" button and start the engine.
- Push the red "emergency stop" button of the platform to the off position.

Result: The engine is off and no function can be operated.

Test the Horn

- Press the horn button.

Result: The horn sounds.

Test the Foot Switch

- Push the red "emergency stop" button of the platform to the off position.
- Rotate the red "emergency stop" button to the on position and do not start the engine.
- Press down the foot switch and try to start the engine by pulling the start toggle switch to either side.

Result: The engine does not start.

- Do not press the foot switch and restart the engine.
- Do not press the foot switch and test the machine's functions.

Result: None of the functions are running.

Test the Machine Function

- Press down the foot switch.
- Start each function control handle or toggle switch on the machine.

Result: All boom/platform actions work properly in one full cycle.

Test the Auxiliary Power Function

 **Caution: Perform this step when the engine is off. In order to save battery energy, test each function in half a cycle.**

- Turn the key switch to the work platform control.
- Turn the red emergency stop button to the "on" position on the work platform control and press the foot switch.
- Press the emergency power unit switch to the "on" position and turn on each function control handle or toggle switch.

Result: All arm and steering functions and drive functions do not function.

Test the steering

- Press down the foot switch.
- Press the left side of the thumb stick switch on the top of the drive control handle.
- Press the right side of the thumb stick switch on the top of the drive control handle.

Test the Drive and Brake Function

- Press down the foot switch.
- Move slowly the drive control handle forward until the machine begins to move, and then return the handle to the center position.

Result: The machine stopped suddenly.

- Move slowly the drive control handle backward until the machine begins to move, and then return the handle to the center position.

Result: The machine stopped suddenly.

 **Caution: The brakes must be able to stop the machine on any slope that it can climb.**

Test the Tilt Angle Sensor

- Start the engine and drive the machine to a certain slope, then make the turntable tilt 4.5° along the direction of the boom.

Result: The alarm on the platform sounds.

- Drive the machine to a certain slope, and then make the machine tilt 4.5° degrees along the vertical direction to the boom.

Result: The alarm on the platform sounds.

- Drive the machine to a certain slope to make the alarm sound.
- Start all boom functions in succession.
- Operate the handle to start the turntable Swing function.

Result: After raising the main arm to a 0.9m, it cannot continue to change amplitude upwards. After raising the tower boom section to 0.9m, it cannot continue to change amplitude upwards. The base boom section cannot continue to extend after an extension of 0.6m. The rest of the boom functions can be used normally, the turntable cannot be rotated.



Caution: If the turntable tilts

4.5° along the direction of the boom or 4.5 along the vertical direction of the boom, the main arm or the tower boom section can be raised more than 0.9m, or the base boom section can extend more than 0.6 m. The machine should be marked immediately and stopped using.

Test the Axle Oscillation Cylinder

- Start the engine on the platform.
- Drive the right steering wheel to a 15cm high obstacle or curb.

Result: The other three tires are in close contact with the ground.

- Drive the left steering wheel to a 15cm high obstacle or curb.

Result: The other three tires are in close contact with the ground.

- Drive the left rear wheel to a 15cm high obstacle or curb.

Result: The other three tires are in close contact with the ground.

- Drive the right rear wheel to a 15cm high

obstacle or curb.

- Result: The other three tires are in close contact with the ground.

Test the Drive Enabling System

- Press down the foot switch and lower the boom to the retracted state.
- Rotate the turntable until the boom is turned to a certain angle beyond a non-steering wheel.



Result: The drive enabling indicator should be illuminated when the boom is at any position within the range shown.

- Move the drive control handle away from the center position.

Result: The drive function does not work.

- Move the drive enabling toggle switch to the upper side while slowly moving the drive controller handle away from the center position.

Result: The drive function can be operated.



Caution: When using the drive

enabling system, the machine may travel in the opposite direction of travel and steering control handle movement. Use the color-coded direction arrows on the drive chassis to determine the direction of movement.

Test the Limited Drive Speed

- Press down the foot switch.
- Raise the base boom section 0.9m.
- Move slowly the drive control handle to the full drive position.

Result: When the base boom section is lifted, the maximum drive speed of AR14J/AR16J does not exceed 0.8km/h, and that of AR19J shall not exceed 1.1km/h.

- Lower the base boom section to the

retracted state.

- Raise the folding boom 0.9m.
- Move slowly the drive control handle to the full drive position.

Result: When the folding boom is lifted, the maximum drive speed of AR14J/AR16J does not exceed 0.8km/h, and that of AR19J shall not exceed 1.1km/h.

- Descend the folding boom to the retracted state
- Extend the base boom section by about 0.6m.
- Move slowly the drive control handle to the full drive position.



Drive enabling

Result: When the boom is in the extended state, the maximum drive speed of AR14J/AR16J does not exceed 0.8km/h, and that of AR19J shall not exceed 1.1km/h.

⚠ Caution: If the drive speed of AR14J/AR16J exceeds 0.8km/h (1.1Km/h for AR19J) when it is raised or extended, the machine should be tagged out immediately and stopped.

⚠ Caution: If the time it takes the boom to rotate for a circle in the extended state is less than 82s, the machine should be marked immediately and stopped.

Test the Drive/Boom Function

- Press down the foot switch.
- Move the drive control handle away from the center position and start a boom function handle or toggle switch.

Result: All boom functions should be operational. The machine moves in the direction indicated on the control panel.

Chapter 9 Operating Instructions

9.1 No Operation is Allowed Unless

You have understood and practiced the principles about safe operation of the machine in this manual.

- 1) Avoid dangerous situations.
- 2) Always perform a pre-operation inspection.
- 3) Check the workplace.
- 4) Always perform a pre-use functional test.
- 5) Use the machine only for its intended purpose.

9.2 Basic Principles

- 1) The vehicle is a self-propelled hydraulic drive lifting device which is equipped with a working platform on an articulating boom mechanism. The vibration generated when the vehicle is running will not be dangerous to the operator who stands on the work platform. The vehicle can be used to load workers and their portable tools to a certain height from the ground, or to reach a certain working area above the vehicle or equipment.
- 2) The Operating Instructions section provides specific instructions for all aspects of vehicle operation. It is the operator's responsibility to follow all safety rules and instructions in this manual.
- 3) This machine is designed for lifting workers and tools to the overhead workplace, it is unsafe or even dangerous to use the vehicle for other purposes.



Caution: This vehicle is strictly prohibited from transporting goods.

- 4) Only trained and authorized personnel can operate the vehicle. If more than one operator uses the same vehicle at different times during the same work shift, they must be qualified operators and follow all safety rules and instructions in the Operation and Maintenance Manual. This means that every new operator should perform

pre-operation inspections, functional tests and workplace inspections before operating the vehicle.

9.3 Starting the Engine

- 1) From the ground control station, turn the key switch to the required position.
- 2) Ensure red "Emergency Shutdown" buttons on the lower control box and the upper control box are pulled to the ON position.
- 3) Turn the engine startup switch to upper side for 2s to 3s. If the engine fails to start or starts up and then stalls immediately, disenable the startup switch for 3s.
- 4) If the engine fails to start in 5-10s (the continuous working time of the starting motor should not exceed 15 seconds), diagnose the reason and repair the fault. Wait for over 1 minute before trying to restart the engine. If it cannot start for three times, please determine the cause and repair the fault. You should wait 60 seconds before trying to start again.
- 5) At -6°C and lower temperatures, keep the engine at idle speed for 5 min prior to operation of the machine to prevent damage to the hydraulic system or the engine.
- 6) At temperatures lower than -18°C , a boosting battery may be used to try and start the engine.



Caution: During startup at low temperature, turn the preheat switch to upper side, keep it activated for 5s to 10s, then turn back the switch and stop preheating.

9.4 Emergency Stop

- 1) Push the red emergency shutdown button on the ground or upper control box to the "OFF" position to stop all functions and shut down the engine.
- 2) If any operational functions need to be fixed, it is necessary to implement after pressing the

red “Emergency Shutdown” button.

3) Select and operate the red “Emergency Shutdown” button of the lower control box to shut down the platform.

9.5 Auxiliary Power

If the main power fails, the auxiliary power should be used.

- 1) Turn the key switch to the ground or platform for control.
- 2) Pull out the red “Emergency Shutdown” button to the “ON” position.
- 3) When operating the power unit (i.e., emergency pump) on the platform, press the foot switch.
- 4) Enable the desired function while keeping the power unit (i.e., emergency pump) open. The drive function will not work with the power unit.
- 5) Do not use the auxiliary power for a period of more than 30min.

9.6 Operation from the Ground Control Station

- 1) Turn the key switch to the lower control box.
- 2) Pull the red “Emergency Stop” button to the “ON” position.
- 3) Push the engine startup switch of the engine to the start position for 2s to 3s, followed by starting up the engine.
- 4) Adjust platform position.
 - Press and hold the function enabling button.
 - Move the proper toggle switch according to the mark on the control panel, and adjust the platform to a suitable position. Driving and steering functions cannot be used from the ground.

9.7 Operation from the Platform Control Station

1) Turn the key switch to the upper control box position.

2) Pull out the red “Emergency Shutdown” buttons on the ground and the platform to the “ON” position.

3) Push the engine startup switch to the start position for 2s to 3s, followed by starting up the engine. Do not step down on the pedal switch when starting up the engine.

4) Adjust platform position.

- Step down on the pedal switch.
- Slowly activate the function control handle or the toggle switch as per the icon on the control panel.

5) Steering

- Step down on the pedal switch.
- Turn the steering wheels by pushing the thumb rocker on the top of the control handle. Press the button on the left side of the thumb rocker, the steering wheel of the machine will turn left; and press the button on the right side of the thumb rocker, the steering wheels of the machine will turn right.

 **Caution: Determine the steering direction of the wheels using the direction arrows on the upper control box and the machine chassis.**

6) Driving

- Step down on the pedal switch.
- Increase the speed: Slowly move the driving controller handle, making it off center.
- Decrease the speed: Slowly move the driving controller handle, making it point at the center.

Stop: Return the driving control handle to the center position or release the pedal switch.

 **Caution: Determine the direction of driving the machine using color label direction arrows on the upper control box and the driving chassis.**

7) Drive the machine on a slope.

- Determine the uphill, downhill and side

slope ratings of the vehicle.



Maximum slope rating, platform downhill: 25% (14°)



Maximum slope rating, platform uphill (climbing ability): 45% (24°)




Maximum slope rated value: 25% (14°)

⚠ Caution: The slope rating is limited by the ground conditions and traction.

- Make sure the boom is below horizontal position and the platform is between the non-steering wheels. Turn the speed select switch to the slow (turtle) or creep (snail) position.
- Determine the slope using the following procedure.

Measure the slope with a digital inclinometer or follow the steps below.

- ✓ The following tools are required: Carpenter's ruler, straight block at least 1 m long, and a tape measure.
- ✓ Place the wood block on the slope, place the carpenter's ruler on the upper edge of the wood block at the end of the downhill slope and raise the end of the block until it is level.
- ✓ Keep the block level and measure the vertical distance from the bottom of the block to the ground.
- ✓ d) Divide the tape measure distance (the raised height) by the block length (travel) and multiply by 100.



Example:

Wood block = 11.8ft
 Travel = 11.8ft
 Raised height = 0.98ft
 $0.98/11.8=8.3\%$ rating

If the slope exceeds the maximum uphill, downhill or side slope rating, the vehicle must be lifted or transported up and down the slope. See the Transportation and Lifting section for further instructions on transporting the machine.

8) Drive enabling

- If the indicator is on, it indicates that the boom has moved beyond one of the two non-steering wheels and the drive function is disabled.
- To drive, turn the driving enabling switch to either side, while slowly moving the driving control handle away from the center position.

Note: The vehicle may move in the opposite direction to the drive and steering control handles.

- Always determine the direction in which the vehicle drives according to the directional arrow on the upper control box.

9) Selection of drive speed

- The machine is located at sign on the slope: The engine is switched to high idle speed automatically. To acquire more driving torque, select the slope sign on the inclined or rough ground.
- The machine is located at the sign on the horizontal plane: For operation of maximum driving speed.

10) Selection of engine idle speed

- Select engine idle speed with the sign on the control panel.
- In the case of failure to stepdown of pedal switch or toggling of handle, the engine will keep idle speed at the lowest revolution.

Turtle sign: Step down on the pedal switch to activate low idle speed.


Rabbit sign: Step down on the pedal switch to activate high idle speed.

9.8 Platform overload

The platform overload indicating lamp is ON, and the alarm gives an alarm, indicating the slight overload of platform. Unload the platform until the lamp is OFF before continuing to operate.


9.9 Tilt Indicator

If the lamp is on, it indicates the vehicle is not level. When the indicator is on, the alarm will sound and the vehicle must be moved to a hard, level surface. Determine the state of the articulating boom on slope, as shown below. Before moving the machine to the solid and horizontal ground, lower the articulating boom per the following steps. Before lowering the boom, do not rotate the boom.



If the tilt alarm sounds on the up-slope of platform:

1. Lower the first boom.
2. Lower the second boom.
3. Retract the first boom.



If the tilt alarm sounds on the down-slope of platform:

1. Retract the first boom.
2. Lower the second boom.
3. Lower the first boom.

9.10 System Fault

The alarm sounds, and the system fault indicating lamp is ON, indicating that the control system has a fault. The LED display will show the corresponding fault code, and the

corresponding functions of the machine will be shut down, shown as Table 9-1.

When the system indicating lamp is ON, operate as per the following steps:

- 1) Lower and retract boom.
- 2) Move the machine to the stowed position, shut down the engine, tag out the machine and shut down.
- 3) The machine can be used again only after relevant qualified personnel maintain, troubleshoot and conduct complete inspection.
- 4) System fault code is shown as the following figure:

5)

Fault Code	Fault Description	Limit Action	Fault Code	Fault Description	Limit Action
1	Cutoff of controller output power supply 1	Limit all actions	12	Fault of left handle	Amplitude of variation on principal arm
2	Cutoff of controller output power supply 2	Limit all actions	13	Fault of right handle	Amplitude of variation on principal arm
3	Cutoff of controller output power supply 3 and 4	Limit all actions	14	Fault of middle handle	Amplitude of variation on principal arm
4	Disconnection of CAN bus of extended module of electric box of platform	Limit all actions	15	Check error of main arm travel switch	Limit all actions
16	Check error of tower boom section travel switch	Limit all actions	17	Check error of main arm extension travel switch	Limit all actions
8-11	Fault of weighing sensor	Amplitude of variation on principal arm	18	Check error of drive enable travel switch	Limit all actions

Table 9-1 System fault codes and limit actions

9.11 Parking and Storage

- 1) Select a solid, level, and safe position where it is moisture-proof, high-temperature resistant, open flame resistant, free from corrosive gas and well-ventilated.
- 2) Retract and lower the boom to the stowed state.
- 3) Close and lock all enclosures and box doors.
- 4) Wipe up dust and oil dirt on the machine body, and keep the machine clean.
- 5) Rotate the turntable to make the boom located between non-steering wheels.
- 6) Turn the key toggle switch to the "OFF" position, and remove the key to avoid unauthorized use.
- 7) During long-term storage:
 - Disconnect the positive and negative electrodes of the battery, drain the fuel completely, and prior to use, conduct overall cleaning and maintenance on the entire machine.
 - When the storage period exceeds three months, run the machine for not less than one hour every three months, and conduct cleaning and maintenance.
 - Secure the wheels using wheel chocks

9.12 Instructions for skyguard

- 1) The Skyguard protective system aims to create safe and convenient operating environment for operators on the basis of ensuring operation convenience, the loading capacity of the platform and the operators' field of view.
- 2) The Skyguard protective device is disposed above the control panel of the platform. If the safety pole is stressed, the protective system will be activated instantly, and the device will stop all actions immediately, thereby preventing operators from suffering

from secondary injury.

- 3) In the extreme case, the safety pole in the protective device will slip to the bottom to ensure operators have sufficient space for buffering and operation. Upon the activation of the Skyguard protective system, the device will give an alarm prompt tone immediately while the blue alarm light flickers. Through the above two approaches, other site operators are reminded, and the safety awareness of neighboring personnel is improved. In addition, the Skyguard protective system also provides the safety overriding switch for operators, facilitating operators to remove dangers. Benefiting from rigid components of the Skyguard protective system, the reliability of the system is improved greatly, and regular or additional maintenance is reduced.

9.13 Fall protection

- 1) Personal fall protection equipped is required when operating the machine.
- 2) All PFPE must comply with applicable governmental regulations, and must be inspected and used in accordance with the PFPE manufacturer's instructions.

Chapter 10 Instructions for Transportation and Lifting

10.1 Compliance

- 1) Only personnel with high-altitude lifting qualifications can load and unload the vehicle.
- 2) The transport vehicle must be parked on a level surface.
- 3) When loading the vehicle, the transport vehicle must be secured to prevent movement.
- 4) Make sure the transport vehicle's capacity, loading surface, chains or belts are sufficient to withstand the weight of the vehicle. Refer to the nameplate for the weight of the vehicle.
- 5) Make sure the turntable has been secured with the rotation lock before transporting. Make sure to unlock the turntable before operation.
- 6) Do not drive the vehicle on a slope that exceeds the vehicle's uphill, downhill or slope rating. Refer to "Drive on the Slope" in the "Operation Instructions" section.
- 7) If the slope of the transport vehicle exceeds the maximum slope rating, the winch must be used to load and unload the vehicle as specified.
- 8) The vehicle is equipped with a sophisticated weighting system. It is forbidden to place heavy goods on the platform, when the vehicle is transporting, otherwise the weighting system may be damaged.

10.2 Freewheel configuration for trailers

- 1) Wedge the wheel to prevent the vehicle from moving.
- 2) Flip over the drive hub cover to release the non-steering wheel brake.
- 3) Make sure that the winch cable is properly secured to the fastening point of the drive chassis and that there are no obstacles in the moving direction.



After the vehicle is loaded:

- ① Wedge the wheel to prevent the vehicle from moving.
- ② Flip over the drive hub cover to engage the non-steering wheel brake.


⚠ Caution: Do not tow the vehicle. If the vehicle must be towed, the speed may not exceed 3.2km/h.

10.3 Transportation Safety

- 1) The turntable rotating lock pin should be used each time the machine is transported.
- 2) The vehicle wheels must always be locked when preparing for transport.
- 3) Before transporting, turn the key switch to the "OFF" position and remove the key.
- 4) Thoroughly inspect the vehicle to prevent loose or unsecured parts.
- 5) Secure the vehicle to the transport surface with the fastening points on the chassis.
- 6) Use at least four chains or belts.
- 7) Make sure the chain or belt used has sufficient load strength.
- 8) Adjust the sling to prevent damage to the chain.



- 9) Make sure that the Jib and platform are telescoped. Protect the platform with the nylon strap on the platform base near the platform rotator (as shown below). Do not apply excessive downward force when protecting the boom components.




10.4 Lifting instructions

Keep in mind the following:

- 1) Only qualified rigging personnel can assemble the sling and lift the vehicle.
- 2) Make sure that the crane's lifting capacity, loading surface, belt or rope is sufficient to withstand the weight of the vehicle. Refer to the label and nameplate for the weight of the vehicle.

Lifting instructions

- 1) Lower and retract the boom completely. Lower the Jib completely. Remove any loose parts from the vehicle.
- 2) Determine the center of gravity of the vehicle with the help of the picture below.
- 3) Only connect the lifting sling to the specified lifting point on the vehicle. There are four lifting points on the chassis.
- 4) Adjust the sling to avoid any damage to the vehicle and keep the vehicle in a level position.



AR14J/AR16J
Mobile Elevating Work Platform
Operation and Safety Manual

880*1230 mm 16 format 8 printed sheets

First edition and printed for the first time in February 2021

Lingong Group Jinan Heavy Machinery Co., Ltd.

Add: 12th Floor, Building 3, Lushangguoaocheng, 9777 Jingshi Road, Lixia District, Jinan, China

Tel: 86-0531-67605017

Fax: 86-0531-67605017

Technical service: 86-0531-67605017

Web: www.LGMG.com.cn

Accessories sales: 86-0531-67605016